Ref: ds\_C02D\_0209 Ver1.0.



# Duct Carbon Dioxide Sensor A/CO2-D

Page 1 of 1

### Description

CO2 transmitters can be used in a broad range of applications including air quality monitoring in buildings. CO2 concentration levels in buildings are monitored to provide an indication of occupancy and to drive a ventilation control strategy. An effective DCV (Demand Controlled Ventilation) strategy will conserve energy and maintain indoor air quality.

#### **Technical Specification**

Measurement Range:	0-2000 PPM factory calibrated
Duct Air Velocity:	0 to 450 meter/min
Temp Dependence:	0.2% of full scale per °C
Stability:	<2% of full scale over the life of the sensor (15 years typical)
Accuracy:	±40 ppm +3% of reading @ 22°C (72°F) when compared with a factory certified reference
Non-linearity:	<1% of full scale @ 22°C (72°F)
Pressure Dependence	: 0.13% of reading per mm of mercury
Calibration:	Sensors will be calibrated at zero and span at the factory. Calibration in the field will not be required. Sensors will be shipped with ABC Logic™ turned on.
Response Time:	Three minutes typical for a 90% step change at low duct speeds
Sampling Rate:	Every two seconds, 25% duty cycle
Warm-up Time:	< two minutes (operational); 10 minutes to achieve maximum accuracy
Operating Conditions:	Temperature: 050°C Humidity: 095% RH, non-condensing
Storage Conditions:	-20°C70°C
Output:	010 Vdc
Power Supply:	1830 Vac, 50/60 Hz or 1842 Vdc
Dimensions:	Probe Length: 10.46 cm Probe Diam: 3.14 cm Junction Box Depth: 4.06 cm Height: 7.62 cm

Note: The A/CO2-D offers patented ABC Logic<sup>™</sup> software for self correction of drift to better than ±20 ppm per year. The system is virtually free of maintenance and typically has a lifetime of more than 10 years.


### Order Code

A/CO2-D Duct Carbon Dioxide Sensor

# Features

- Simple installation (mounting hardware included)
- Ideally suited for larger HVAC return air ducts
- Offers standard 0-10 volt output
- Patented absorption infrared/gas sensing engine provides high accuracy in a compact low-cost package
- Patented ABC Logic<sup>™</sup> self-calibration system eliminates the need for manual calibration in most applications
- Lifetime calibration guarantee.

## Installation & Wiring



- **1.** Before installing sensor, note the direction of the airflow. Ensure all mounting holes are sealed tightly.
- 2. Drill/Cut one  $1\frac{1}{2}$ " hole / Punch/Drill one 1/8" hole.
- 3. Slide sensor into 1  $\frac{1}{2}$  hole and secure with screws.
- 4. Connect conduit and make necessary wire connections.
- 5. Install lid, ensure it snaps into place.

E.C. Products Limited - Head Office EC House, Amberley Way, Hounslow Middlesex, TW4 6BH, United Kingdom

Tel: +44 (0)20 8569 4100 Fax: +44 (0)20 8569 4111

ECP reserves the right to change the information contained in this datasheet as and when required without notice. Users must take care to use the information contained in this leaflet. ECP will not accept the liability for damages, loss and expenses that may be caused by omissions and errors in the information provided.